

# SSL BIG SIX ROUTING & USING THE FEATURES

## Connecting Your SSL Big Six To Your Windows PC.


Plug in the usb lead and turn on the SSL then download the driver for the SSL if you have a windows pc.

<https://www.solidstatellogic.com/products/big-six?tab=documentsanddownloads>

## Playing tracks/Youtube from your computer.

Connect your monitors to the rear of the SSL. (Turn on last)

*BiG SiX Rear Connectors*



Check you have both lights on, power and usb.



Press down the 15/16 button



Above the Monitor is the Monitor Source section. Press down EXT 2.

→ The meter light should come on when music is on.




→ Note: This adjusts the volume too.



**Check you pc has it set up correctly.**

On Your PC go to settings.

Search sound, push sound settings under sound in windows you should see the SSL come up and default to 15/16



Sound

Output

Choose your output device

- Output 15/16 (SSL BiG SiX USB Audio Device)
  - Output 3/4 (SSL BiG SiX USB Audio Device)
  - Output 5/6 (SSL BiG SiX USB Audio Device)
  - Output 9/10 (SSL BiG SiX USB Audio Device)
  - Output 7/8 (SSL BiG SiX USB Audio Device)
  - Output 1/2 (SSL BiG SiX USB Audio Device)
  - Speakers / Headphones (Realtek Audio)
  - Output 13/14 (SSL BiG SiX USB Audio Device)
  - Output 11/12 (SSL BiG SiX USB Audio Device)
- [Manage sound devices](#)

Make sure the volume is down, then turn on your monitors and play a track turning up the volume on the monitor.



MONITOR

**Disclaimer:** Please refer to your manual, I cannot be held responsible for any issues that you may run into.